Portable P.A. System W/ USB/SD & IPOD DOCK

User's Manual

Before using your new Portable PA System, please read this instruction manual to prevent any damage. Put it in a safe place for future references.

FEATURES

- Convenient portable PA package with handle and wheels for easy transport
- 7-channel 300W powered mixer
- Stereo two-way speaker system with 10” woofer and piezoelectric tweeter horn, speaker cables, two folding speaker stands
- XLR and1/4” mic/line inputs
- Stereo source inputs for CD, VCR or DVD or other audio sources
- Bass, treble and reverb controls ,16DSP
- USB/SD dock for MP3 player system with large LCD
- Five-band graphic equalizer
- Dynamic microphone
- Storage compartment for microphones, cables and accessories
- Stereo RCA auxiliary outputs

WARNING

An equilateral triangle enclosing a lightening flash/arrowhead symbol is intended to alert the user to the presence of uninsulated dangerous voltage within the product’s enclosure which may be of sufficient magnitude to constitute a risk of electric shock.

An equilateral triangle enclosing an exclamation point is intended to alert the user to the presence of important operating and service instructions in the literature enclosed with this unit.

CONTROLS



1. CH1-CH4 MIC INPUT

The XLR & 1/4" Jack mic input are electronically balanced XLR & 1/4" type designed to accept mic level signals from any balanced or unbalanced low impedance microphone.

2. MIC/LINE INPUT SWITCH

This button switch for MIC/LINE input

3. TREBLE CONTROL

This button allow you to adjust treble.

4. MIDDLE CONTROL

This button allow you to adjust middle.

5. BASS CONTROL

This button allow you to adjust bass.

6. VOLUME CONTROL

This button allow you to adjust MIC/LINE input volume

7. CH5-CH6 LINE INPUT

The 1/4" Jack input are electronically stereo input for audio source

8. CH7-CH8 RCA INPUT

The RCA input are electronically stereo input for audio source

9. RCA OUTPUT
This connector output the audio source to another active amplifers

10 LINE INPUT / RCA INPUT SWITCH
This knob switch for Line input or RCA input

11. LED LIGHT INDICATE
This LED lights indicates volume level

12. ECHO LEVEL CONTROL
This knob allow you to adjust the microphone echo effects

13. USB/SD IPOD LEVEL CONTROL
This knob allow you to adjust the volume of UBS/SD & IPOD DOCK

14. MASTER LEVEL CONTROL
This knob allow you to adjust the volume of amplifier output

15. 5-BAND EQUALIZER
This equalizer allow you to adjust the Bass, Mid, Treble effects

16. USB/SD MP3 PLAYER
This unit is USB / SD mp3 player with Blue LCD display

17. IPOD DOCK STATION
This unit is IPOD dock stations for IPOD / IPHONE connecting

CONTENT

1pc Power mixer
2pcs Speaker box
2pcs Folding speaker stand
2pcs Speaker cable-9 meter
1pc Microphone cable- 6meter
1pc Microphone
1pc Ac cord